




Barn Owl Assembly Instructions



Parts list:


- 1 Floor panel
- 1 rear panel
- 1 front entrance
- 2 sides (left and right)
- Fledge tray
- Brackets



STEP 1: Place the floor panel on the work surface with the rough side facing upwards.




STEP 2: Put the rear panel in place and ensure that the aluminium bracket is beneath the floor panel



STEP 3: Put the front panel in place and ensure that the aluminium bracket is beneath the floor panel.



STEP 4: Insert one of the side panels by sliding the aluminium angle beneath the floor panel.



STEP 5: Place the second side panel in place with the aluminium angle beneath the floor panel.



STEP 6: Insert bolts provided into the front and rear panels through the pre-drilled holes. Place a washer on each bolt inside the box before fitting the nuts. A 7mm spanner is required to tighten the bolts.




STEP 7: Fix the two aluminium brackets to the front face of the nest box and put a bolt through each pre-drilled hole and use a washer and bolt to fix the brackets to the outside of the nest box.



STEP 8: Put the fledging tray onto the brackets with the framed side upwards. Place a bolt through each pre-drilled hole in the fledging tray panel and then tighten using the nuts provided.



STEP 9: Check all nuts to ensure that they are fully tightened and fix the roof onto the nest box using the bolts and 2 self-drilling Tec screws provided. Place the roof on the nest box with a large overhang at the front. Mark the position of the brackets and use the 2 Tec screws to hold it in place.



STEP 10: Your box should now be assembled. Please see our website for installation instructions. Two ratchet straps (**Not included**) should be used to fasten the box in your chosen location ensuring that the nest box is held securely in place.

<https://genesishnestboxes.ie/genesish-nest-box-materials/installation-instructions/>

If you encounter any difficulties while following these instructions, please contact Stephan on 086 108 7266 for help.